

KT-B02 Universal air conditioner remote controller

KT-B02 Universal air conditioner remote controller


STOCK CODE:K0005263

KT-B02 Brand Code Table

Brand	Model Code	Brand	Model Code
ALPIN	0252, 0253, 1788, 3325	LITTLE DUCK	0527, 0532, 1556, 2070
AUCMA		LOREN SEBO	0288, 0471, 0472, 1496, 3543
AUX	0297-0300, 0451, 2860, 3370	MACQUAY	0234-0237, 0455, 2283, 3820
BANSHEN		MICOM	0415, 1439, 2468
BOERKA	0383, 0434, 0436, 0437, 3967	MIDEA	0260-0265, 1284, 2310
CARRIER		mitsubishi	0001-0045, 0476-0479, 3628
CHANGHONG	0301-0308, 1325, 2353, 3982	NORITZ	0431, 1455, 2468
CHIGO		PANASONIC	0138-0154, 0483, 2019, 3738
CHOFU	0184-0187, 1721, 3771	National	0138-0154, 0483, 2019, 3738
CHUNLAN		PANDA	0378, 0890, 1405
CORONA	0155-0163, 0459, 2206	PHILCO	0210, 0211, 0487, 0488, 3795
CONROWA		PROTON	0421-0423, 2507, 3593
CONSUL	0463, 0975, 2511	RAYBO	0362-0367, 1387, 2925
DAEWOO		ROWA	0369, 0438, 0439, 1975, 3510
DAIKIN	0171-0183, 2220, 3758	Sabro	0435, 0506-0508, 2483, 3579
DOCTOR		SAIJO DENKI	0212-0215, 1238, 3285
DONGBAO	0355-0361, 2403, 3430	SAMPO	0424-0426, 1448, 3497
DONGXINBAO		SAMSUNG	0188-0196, 2239, 3772
Electrolux	0216-0220, 1753, 3802	SANYO	0046-0095, 0559, 1090, 3678
FRESTECH		SASUKI	0254, 0470, 2006, 3838
FUJITSU	0127-0137, 0464, 1158, 3720	SHANGLING	0384-0388, 0444, 0445, 3969
FUNAI		SHARP	0096-0106, 1633, 2150, 2656
GALANZ	0371, 0372, 1395, 2933, 3956	SHINCO	0351-0354, 0454-0456, 2912
General		SHUANGLU	0376, 0404-0407, 0480, 2476
GLEE	0398, 0399, 2446, 3983	SHUAKANG	0288, 0800, 1311
GOLDSTAR		SONGGE	0428, 0429, 1965, 2988
GREE	0309-0316, 0482, 0512, 0513	SOVA	0409, 0410, 2457, 3482
HAIER		SUMMER	0427, 1963, 2485, 3499
HISENSE	0332-0335, 1869, 2895, 3917	SUNDURG	0257, 0505, 1793, 3841
HITACHI		SWAN	0434, 0946, 1556
HUABAO	0336-0344, 1879, 3409, 3926	TADIRAN	0246-0251, 2295, 3833
HUAKE		TATUNG	0419, 0420, 1955, 2979
HUAMEI	0402, 0460-0465, 1997, 3533	TCL	0273-0281, 1299, 3347
HUALING		TECO	0256, 0473-0475, 1280
HUIFENG	0370, 0882, 2420, 3954	TIANDI	0415, 0927, 1538, 3999
HUIKANG		TOSHIBA	0107-0117, 0489, 1647, 3181
HYUNDAI	0202, 0433, 0480, 1226, 2250	TRANE	0227-0232, 0789, 2276
JDC		UNI-AIR	0222-0224, 0450, 3522
JINDA	0414, 1950, 2536	WEILI	0393-0396, 2442, 3979
JINSONG		Whirlpool	0164-0170, 0502, 2038, 3752
JOHSON	0245, 0492, 2028, 3829	WINIA	0481, 1505, 3553
KANGLI		XILENG	0411, 0412, 2460, 3995
KELON	0282-0287, 0473, 0485-0488	XINLE	0400, 0401, 2960, 3985
KLIMATAIR		YANGZI(YAIR)	0403, 1427, 3475
KOLIN	0416-0418, 1952, 2465, 3539	YINYAN	0258, 0259, 0326, 0331, 2888
KONKA		YORK	0238-0243, 2287, 3312
LG	0197-0200, 0514, 2050, 3730	Zhen bao	0639, 1164, 2176, 3200
LIANGYU			


Batteries:AAA x 2

MADE IN CHINA



MITSUBISHI
PANASONIC
TOSHIBA
HITACHI
SANYO
SAMSUNG
DAIKIN
LG
FUJITSU

III. Automatic search
(press and hold
"SELECT" 5
seconds for all
other brands)
IV. Manually code setting



Product Description

Thank you for choosing our remote, it is honored that we can provide conveniences for your life.

KT-B02 is a new product with several patent technologies which is invented by our engineers. No matter winter or summer, operation by one key, also suitable for children and the older.

KT-B02 is a universal air conditioner remote control with 6000 codes, suits for domestic, international brands; old and new types, etc, it can be used for 98% air conditioners in the world. This remote also has clock, timer on and off, room temperature display and other functions, etc. It is the best choice for you to replace the remote.

Setting

Put 2 AAA(UM-4,R03)batteries as per polar indicated on battery cabin.Choose one of the setting methods as below.

Code input

- 1、 Find out the codes from code table,there are many groups codes of each brand. Please try the first group, if it does not work , try the second, and do it like this until the codes can operate your equipment.Ex: AUCMA, you can choose 0288, if it does not work, please try the 0289.
- 2、 Aim to the air conditioner, press "one key" ,check whether it is work or not, if it works, setting succeed , if not, try another group until it works.

Automatic search

If you do not know the brand of your air conditioner, or if your brand is not listed in the code table, please operate as per following steps:

- 1、 Put the remote control aim at your air conditioner,press the "SELECT" key for 5 seconds and then release, remote control is entering the autosearch status, emit the signal continuously, the code flashes and increases. While the air conditioner receives the signal ,and send one buzzer,press any key to confirm.

Clock set up

- 1、 Press the "CLOCK" button, it is blinking.
- 2、 Press the time "+" or "-", setting to the current time.
- 3、 Press the "CLOCK" button again,stop blinking, the time setting is complete.
(If you did not press the "time" button, it can be setting automatically after 5 seconds)

TIMER ON AND OFF

No matter whether the air conditioner on or off you could set the timer on and off at the same time.

- 1、 Press the "TMR on" button, the LCD displays the clock signal and time blinking.Press "TIME/code" "+" "-" button,adjust to the required time,and it will confirm the turn on after 5 seconds.
- 2、 Press the "TMR off" button,the LCD displays the clock signal and time blinking.Press "TIME/code" "+" "-" button,adjust to the required time,and it will confirm the turn off after 5 seconds.

Note:

- 1、 The time frame can be set between 00-24 hours;
- 2、 Press the "timer on" or "timer off" two times continuously,cancels the timing.
- 3、 After timing setting, the launch direction of remote control must be aim at the receive direction of your air conditioner in the effective distance, otherwise the timing setting ineffectively.

Temperature display

Press "temp" to display the room temperature, and it will return to setting temperature after 5seconds, so you could use it as a thermometer, offer convenience for controlling the temperature anytime.

Attention

- 1、 If it is not used for a long time, remove the battery to avoid leakage liquid of the battery to damage the machine. When the LCD looks dim, please change batteries. (New and old batteries can not be used together) After the batteries are replaced every time, it is not necessary to set model code again.
- 2、 As usual the LCD only display the time when pressing model codes "Enter" key, you can find the code and it is showed on LCD. After 5 seconds it returns time.
- 3、 Check carefully that there is no remora between remote controller and Air conditioner when the time on/off doesn't work. Because the operation is effective only when the air conditioner receives the timer on/off signal from remote controller.
- 4、 The manufacturer keeps the right to change the parameter and function of product.

Technical Parameters

Controllable distance: Large than 8 meters (According to the machine)
Battery model: Battery AAA(UM-4, R03) × 2
Dimension: L133mm × W45mm × D23mm
Weight: Approx52g (excl.the batteries)