

# KT-e05

Brand	Model Code
AIRWELL	0555, 0556
ALPIN	0252-0253, 1276, 1789
AUCMA	0288-0296, 0462, 1826, 3534
AUX	0297-0300, 0451, 1834, 3011
BANSHEN	0264, 1288, 2824
BOERKA	0383, 0434, 0436, 0437, 3506
CARRIER	0203-0209, 0456-0458, 0482-0486, 0563-0565
CHANGHONG	0301-0308, 2349, 3890
CHIGO	0379-0382, 0515, 1912, 2940
CHOFU	0184-0187, 1208, 2233
CHUNLAN	0345-0350, 0450, 0453, 3522
CORONA	0155-0163, 0459, 2204, 3531
CONROWA	0377, 0889, 1315, 2937
CONSUL	0463, 1999, 3535
CONTRY AIR	0560
DAEWOO	0203-0209, 0406, 1430, 3792
DAIKIN	0171-0183, 0566, 0567, 0583
DOCTOR	0221, 0449, 1473, 3805
DONGASO	0355-0361, 1897, 2918
DONGXINBAO	0413, 1505, 3485
Electrolux	0216-0220, 0569, 1244
ELECTRA	0557
EMAILAIR	0558
FEDDERS	0528
FRESTECH	0277, 0519, 0520, 2325
FUJITSU	0227-0137, 0464, 0552-0554
FUNAI	0430, 0481, 3041, 3502
GALANZ	0471, 0372, 0521, 1908, 2931
GENERAL	0217-0137, 0464, 2000, 3712
GLEE	0398, 0399, 2446, 2959
GOLDSTAR	0201, 0466-0469, 1737, 3539
GREE	0309-0316, 0482, 0512, 0513
HAIER	0266-0272, 0453-0455
HISENSE	0332-0335, 0517, 1868, 2895
HITACHI	0118-0126, 1656, 2173
HUABAO	0336-0344, 2384, 2903
HUAKE	0408, 0920, 1501, 3480
HUAMEI	0402, 0460-0465, 2962, 2986
HUALING	0317-0325, 0452, 2365, 3524
HUIFENG	0370, 2418, 3442
HUIKANG	0368, 0441-0443, 1978, 3440
HYUNDAI	0202, 0433, 0480, 0511, 3552
JDC	0373, 0440, 2488, 3957
JINSONG	0389-0391, 0446-0448, 3463
JOHNSON	0245, 0492, 2028, 3829
KANGLI	0374-0375, 1911, 2442
KELON	0282-0287, 0473, 0485-0488
KLIMATAIR	0225, 0226, 0452, 3297
KOLIN	0416-0418, 2466, 3488
KONKA	0397, 0457-0459, 3017
LG	0197-0200, 0514, 0572, 2248

Brand	Model Code
LIANGYU	0233, 0451, 1987, 3817
LITTLE DUCK	0015-0020, 0530, 1039
LOREN-SEBO	0255, 0471, 0472, 2007, 3327
MACQUAY	0234-0237, 0465, 1489, 2794
MICOM	0415, 1439, 2465, 3487
MIDEA	0260-0265, 0526, 1801, 2820
MITSUBISHI	0001-0045, 0476-0479, 0552, 0553, 0568, 0582
NORITZ	0431, 0943, 2991
OMEGA	0559
National	0138-0154, 0483,
PANASONIC	2714, 3722
PANDA	0378, 1914, 3962
PHILCO	0210-0211, 0487, 0488, 1234
PROTON	0421-0423, 0934, 2981
RAYBO	0362-0367, 2410, 3435
ROWA	0369, 0438-0439, 0527, 0531
Sabro	0435, 0506-0508, 0947, 3578
SAIJO DENKI	0212-0215, 0724, 2262
SAMPO	0424-0426, 1448, 2985
SAMSUNG	0188-0196, 0516, 0518, 1212
SANYO	0046-0095, 0529, 0530, 1070
SASUKI	0254, 0470, 1494, 2814
SHANGLING	0384-0388, 0444-0445, 3407
SHARP	0096-0106, 0525, 1122
SHENGFENG	0376, 0480, 0888, 1911
SHINCO	0351-0354, 0454-0456, 3935
SHUANGLU	0376, 0404-0407, 0480, 1400
SHUAIKANG	0288, 0800
SONGGE	0428-0429, 2988, 3501
SOVA	0409-0410, 1433, 2457
SUMMER	0427, 1963
SUNDURG	0257, 0505, 1529, 2305
SWAN	0434, 0516, 0524, 2994
TADIRAN	0246-0251, 0759, 1787
TATUNG	0419-0420, 2980, 3491
TCL	0273-0281, 0570, 0786
TECO	0256, 0473-0475, 1497, 3840
TIANDI	0415, 1439, 3999
TOSHIBA	0107-0117, 0489, 0561, 0562, 1001
TRANE	0227-0232, 0739, 1101, 1768
UNI-AIR	0222-0224, 0450, 1986
WANBAO	0138-0154, 0483, 0652, 0995
WEILI	0393-0396, 1420, 1932
Whirlpool	0164-0170, 0502, 1526, 3748
WINIA	0481, 0993
XILENG	0411, 0412, 0924, 1947
XINLE	0400, 0401, 0913, 2960
YANGZI(YAIR)	0403, 1427, 2451
YIN YAN	0258-0259, 0326-0331, 0838
YORK	0238-0243, 0751, 1778
ZHEN BAO	0127-0137, 0464, 2000, 3711

STOCK CODE:K0005262

KT-e05  
4000 IN 1



One Key  
Nonstop

Excellent  
shape

Input codes  
directly by  
digit keys

Full function

Permanent  
Memory



UNIVERSAL A/C REMOTE CONTROL



MADE IN CHINA

### Product Description

Valued users:

Thank you for choosing this universal remote control. It is our greatest wish for all my colleagues to offer facilities for your life.

KT-e05, one-key universal AC remote control is a high-tech product with several patents of invention which is invented by our engineers. Whether summer or winter, you could enjoy comfort just by one key. The case with fluent tie-in and gorgeous line is not only for the youth, and big buttons, big screen, big words also for the elder. You could find the function buttons inside the sliding cover, and an outside button especially for the child. And it has the design of differentiation senseless dots also suits for the blind.

KT-e05 is a universal remote that 4000 in 1, you could use it for both domestic equipment and imported equipment (control 98 percent air-conditioner in the world). In addition, the Remote also has clock, timer on and off, room temperature, conversions between Celsius and Fahrenheit degree. So it's your best choice of replacement. Please read this manual and set your remote for your brand before using and we hope it will help you to use this remote.

### Setting of remote

Open the slide cover, put 2 AAA (VM-4, R03) batteries as per polar indicated on the battery cabin. Pull on the slide cover and all the function buttons appear. Set your remote with one of the following methods.

#### 1. Patent code setting up

① Find out the required code from brand code list. If one brand has several groups of codes, you should try the first group. If it doesn't work, try the second and to this analogizes until the remotes can operate your equipment. Ex: AUCMA, you can choose 0288, if it does not work, please try the 0289 etc.

② Press "one-key", the air-conditioner works. If it does not work, try "0289" uses these methods until the air-conditioner can work.

#### 2. Auto-search code setting

If you do not know the brand of your air conditioner, or if your brand is not listed in the code cable, try searching for your code as follows:

① Put the remote aim at your air conditioner, press and hold "SELECT" key for five seconds. The remote is entering the auto-search status. Launch the signal continuously, the code blinking and increasing. When the air conditioner receives the signal, and sends a BUZZER, press any keys to confirm. Note: please press the keys as quickly as you listen to the buzzer, otherwise, you would miss the correct code.

② Put the remote aim at your air conditioner again, press "one-key", the air conditioner works and finish setting. Otherwise setting again use above methods.

### Function indication

#### 1. One-key nonstop function

After setting codes, whether in summer or winter, when you want to use air conditioner, just aim remote at your air conditioner and press the "one-key". Remote can judge the room is in summer or winter according to the current temperature. In summer, the temperature will be set in 26°C. In winter, the temperature will be set in 20°C, and fan middle, swing auto. If you feel not comfortable of the temperature, you could adjust by temp. +/- Of course, the remote also has common functions as original remote.

### Function indication

#### 2. Clock set up

① Press the "CLOCK" button, it is blinking.

② Press the TIME "+" or "-" button, setting to the current time.

③ Press the "CLOCK" button again, stop blinking, the time setting is complete. (If you did not press the "time" button, it can be setting automatically after 5 seconds)

#### 3. TIMER ON AND OFF

No matter whether the air conditioner on or off you could set the timer on and off at the same time.

① Press the "TMR on" button, the LCD displays the clock signal and time blinking. Press TIME "+" or "-" button, adjust to the required time, and it will confirm the time of turn on after 5 seconds.

② Press the "TMR off" button, the LCD displays the clock signal and time blinking. Press TIME "+" or "-" button, adjust to the required time, and it will confirm the time of turn off after 5 seconds.

Note:

① The time frame can be set between 00-24 hours;

② Press the "timer on" or "timer off" two times continuously, cancels the timing.

③ After timing setting, the launch direction of remote control must be aim at the receive direction of your air conditioner in the effective distance, otherwise the timing setting is ineffective.

#### 4. Conversions between Celsius and Fahrenheit degree

People used to the Celsius degree, just press the "C/F", remote will convert the display between Fahrenheit and Celsius degree and display it, and it works both ways.

#### 5. Thermometer function

Except the setting temperature, it also can display the room temperature, so you could use it as a thermometer, offer convenience for controlling the temperature anytime. It could be automatic Fahrenheit and Celsius degree transformation by pressing "C/F".

### Attention

1. If it is not used for a long time, remove the battery to avoid leakage liquid of the battery to damage the machine. When the LCD looks dim, please change batteries. (New and old batteries can not be used together) After the batteries are replaced every time, it is not necessary to set model code again.

2. As usual the LCD only display the time when pressing model codes "Enter" key, you can find the code and it is showed on LCD. After 5 seconds it returns time.

3. Check carefully that there is no remora between remote controller and Air conditioner when the time on/off doesn't work. Because the operation is effective only when the air conditioner receives the timer on/off signal from remote controller.

4. The manufacturer keeps the right to change the parameter and function of product.

### Technical Parameters

**Controllable distance:** Large than 8 meters (According to the machine)

**Battery model:** Battery AAA (UM-4, R03) × 2

**Dimension:** L145mm × W55mm × D16mm

★ The final explanatory right is reserved this company.